

GENERAL LAUNDERING

KEVLAR/ARAMID

1. Use commercial laundry soap/detergent
2. DO NOT BLEACH - oxygen bleach may be used as a replacement
3. Use 170°F/75°C water to wash for 20 minutes
4. Rinse - 1 time in hot water, 1 time in cold water
5. Tumble dry for up to 35 minutes at 155°F/70°C

Kevlar can also be effectively dry-cleaned.

NYLON/COTTON/POLYESTER

1. Wash in 160° F (71° C) water with regular detergent
2. Tumble dry with medium heat
3. May be bleached with oxygenated bleach as necessary

DIPPED GLOVES

1. Wash for 10 minutes in warm water, do not exceed 140° F (60° C)
2. Rinse in 100° F (38° C)
3. Use high speed spin extraction for best results
4. Drip dry or tumble dry. Do not exceed 49°C (120°F) or tumble dry longer than 10 minutes

LEATHER GLOVES

Leather gloves should be dry cleaned, as commercial soaps/detergents remove the natural oils that keep gloves soft and flexible.

Please Note:

It is recommended to try these laundering options with a limited number of products and then analyze the results before proceeding with laundering items in bulk.

Gloves that have been exposed to harsh chemicals or hazardous materials should not be laundered for reuse.