



Class 3 Rain Jackets Sizing Charts

Choosing the correct size in safety apparel is crucial for optimal protection and performance.

For an accurate size and fit in Global Glove safety rain jackets, please refer to the following general sizing dimensions.



Across Chest

ALL MEASUREMENTS IN INCHES

Estimate size to the closest fit.
Body proportions may vary.

RAIN SUIT - JACKETS GLO-8000

SIZE	BODY LENGTH	ACROSS CHEST	SLEEVE LENGTH (FROM CENTER BACK)
SMALL	30	25	34.5
MEDIUM	31	26	35.5
LARGE	32	27	36.5
XL	33	28	37.5
2XL	34	29	38.5
3XL	35	30	39.5
4XL	36	31	40.5
5XL	37	32	41.5

RAIN JACKETS GLO-1400 • GLO-1450

SIZE	GLO-1400 BODY LENGTH	GLO-1450 BODY LENGTH	ACROSS CHEST	SLEEVE LENGTH
SMALL	27	45.25	28.5	24.5
MEDIUM	28	45.25	29.5	25
LARGE	28.75	45.25	30.75	25.5
XL	29.5	45.25	32	26
2XL	30.5	47.25	32.75	26.75
3XL	31	47.25	33.5	27.5
4XL	32	47.25	34.25	28
5XL	32.75	47.25	35	28.5