

TUFFALENE LAUNDERING

Standard Laundering Instructions:

1. Brush large particles from glove
2. Rinse in cold water
3. Use commercial laundry soap or detergent - May be bleached with a solution of 5.25% sodium hypochlorite, (household bleach) diluted to 1:10 as a sanitizer & to help restore whiteness.
4. Wash for 10 minutes in warm water, do not exceed 140° F (60° C)
5. Rinse in 100° F (38° C)
6. Use high speed spin extraction for best results
7. Drip dry or tumble dry. Do not exceed 49°C (120°F) or tumble dry longer than 10 minutes

Special instructions:

When laundering gloves that have especially heavy dirt or grease, throw in several pieces of heavy canvas in the second wash cycle. The agitation of the heavy canvas against the gloves will help to loosen and remove the deepest dirt.

Please Note:

It is recommended to try these laundering options with a limited number of products and then analyze the results before proceeding with laundering items in bulk.

Gloves that have been exposed to harsh chemicals or hazardous materials should not be laundered for reuse.