



HAND PROTECTION

Anti-Static/Electrostatic Compliant High-Visibility Nitrile Dotted Gloves with Cut, Heat, Abrasion, and Puncture Protection

DESCRIPTION

This 13-gauge glove provides heat resistance in a general-purpose style. The high-visibility orange seamless acrylic/polyester/spandex shell is further enhanced by a black Mach Finish nitrile dipped palm for superior wet/dry grip. The palm has nitrile dots for better grip, wear resistance, and short-term heat protection. The knit wrist provides a comfortable, secure fit. Anti-static/electrostatic compliant for use in an ESD protected area.

INDUSTRY

Handling Hot Objects Construction
Automotive Industry Manufacturing

FEATURES

- 13-gauge shell offers heat resistance and increased dexterity
- Abrasion-resistant Mach Finish nitrile offers excellent grip in wet and oily conditions
- Nitrile dotted palm increases abrasion resistance and grip
- High-visibility color allows hands to be easily seen
- Overcast color on hem for easy size identification
- Knit wrist cuff offers users a secure, comfortable fit and prevents gloves from slipping off during use
- Anti-static/electrostatic compliant
- EN 388 Levels: 4X21X
- EN 407 Levels: X2XXXX



ITEM 801

SIZES 7(S)-10(XL)

Meets ANSI/ISEA 105-2016 standard

- Cut Level A2
- ASTM F2992-15 Results = 581 Grams
- Abrasion Level 4
- Puncture Level 2
- Puncture Results: 39 Newtons



SPECIFICATIONS

SHELL	GAUGE	SHELL COLOR	COATING	COATING COLOR	FINISH	DOTTED	CUFF
Acrylic/Polyester/Spandex	13-Gauge	High-Visibility Orange	Nitrile	Black	Mach Finish	Nitrile	Knit Wrist
CUT	ASTM F2992-15 RESULTS	ABRASION	PUNCTURE	PUNCTURE RESULTS	EN 388 LEVELS	EN 407 LEVELS	ANTI-STATIC/ELECTROSTATIC
Level A2	581 Grams	Level 4	Level 2	39 Newtons	4X21X	X2XXXX	Compliant

PACKAGING

	QUANTITY	7(S)	8(M)	9(L)	10(XL)
PAIR UPC	1	NA	NA	NA	NA
INNER PACK UPC	12/PACK	816368024370	816368024387	816368024394	816368024400
CASE GTIN	6 PK/CASE	10816368024377	10816368024384	10816368024391	10816368024407
CASE WEIGHT (IN POUNDS)		9.9	10.6	11.5	12.4
OVERCAST COLOR		Red	Green	Brown	Black

13915 Radium St NW
Ramsey, MN 55303

763-450-0110
Sales@GlobalGlove.com

GlobalGlove.com


Global Glove
& Safety Manufacturing, Inc.