



HAND PROTECTION

Premium Neoprene Rough Etched Finish 32-Inch Shoulder-Length Chemical Handling Gloves

DESCRIPTION

These heavy-wall supported chemical handling gloves are multi-dipped in premium-grade heavy black neoprene for superior quality and durability. They grant protection against chemicals, acids, and solvents. They also offer excellent all-around protection against abrasion hazards. The rough etched finish is excellent for applications where a wet grip is required. Features an antimicrobial-treated cotton interlock liner that reduces bacteria. The gloves are 32 inches long with a gauntlet cuff for extended arm protection.

INDUSTRY

Material Handling	Chemical Processing	Oil and Gas Refining
Cleaning	Petrochemical	Galvanizing
	Degreasing	

FEATURES

- Component materials comply with FDA regulations for food contact
- Multi-dipped in premium-grade black neoprene
- Soft cotton interlock liner is permanently adhered to the shell and adds extra comfort plus durability
- Rough-etched finish enhances grip in wet or greasy situations and provides extended wear
- Antimicrobial treated liner reduces bacteria that cause odors and can lead to dermatitis
- Shoulder length to protect from spills and splashes
- Excellent wet grip
- Protection against alkaline and acids
- Resistant to solvents, greases, and oils



ITEM 9932R

SIZES ONE SIZE

Meets ANSI/ISEA 105-2016 standard

- Grommets at the end of each cuff for easy storage
- Gauntlet cuff allows for easy donning and removal plus extra forearm protection
- EN 388 Levels: 3121X
- EN ISO 374-1:2016/Type B: AKLPT

- Cut Level A2
- ASTM F2992-15 Results = 752 grams
- Abrasion Level 4
- Puncture Level 2
- Puncture Results: 50 Newtons
- Conductive Heat Level 3

SPECIFICATIONS

LINER	COLOR	GRADE	COATING	FINISH	LENGTH	CUFF	ANTIMICROBIAL PROTECTION	FDA FOOD CONTACT
Cotton Interlock	Black	Premium	Triple Neoprene	Rough Etched	32 in.	Gauntlet with Grommet	Yes	Compliant
CUT	ASTM F2992-15 RESULTS		ABRASION	PUNCTURE	PUNCTURE RESULTS	CONDUCTIVE HEAT	EN 388 LEVELS	EN ISO 374-1:2016/TYPE B
Level A2	752 Grams		Level 4	Level 2	50 Newtons	Level 3	3121X	AKLPT

PACKAGING

	QUANTITY	ONE SIZE
PAIR UPC	1	N/A
INNER PACK UPC	12/PACK	816679017450
CASE GTIN	1 PK/CASE	10816679017457
CASE WEIGHT (IN POUNDS)		19

PERMEATION DATA

EN ISO 374-01: 2016	CHEMICAL	PL
A	Methanol	3
K	Sodium Hydroxide 40%	6
L	Sulfuric Acid 96%	2
P	Hydrogen Peroxide 30%	6
T	Formaldehyde 37%	6

Permeation data was measured in two ways:

1. For solvents – Gas Chromatography
2. For acid and bases –
By conductivity measurements

*PL = Performance Level

13915 Radium St NW
Ramsey, MN 55303

763-450-0110
Sales@GlobalGlove.com

GlobalGlove.com


Global Glove
& Safety Manufacturing, Inc.