

# MAKI®

## BULLHEAD SAFETY® EYE PROTECTION

### PFT BH1431PFT



**BH14G**

Optional removable flame-resistant foam gasket is available for all Maki® safety glasses.

**LENS** Clear Performance Fog Technology

**FRAME** Crystal Black

### DESCRIPTION

The fashion sport-inspired design of the Maki® safety glasses can be combined with the optional removable closed-cell EVA foam to protect from airborne particles and debris. It also has dual injected TPR temple ends and embedded rubber nose pieces to ensure a slip-free fit in any environment. The BH1431PFT also features a PFT lens. Thanks to its chemical and physical properties, Performance Fog Technology is a permanent coating that prevents the formation of condensation on the lenses by absorbing the humidity drops.

BH14G - optional removable flame-resistant foam gasket available for all Maki® safety glasses.

### FEATURES

- PFT - Performance Fog Technology lens: Better than traditional anti-fog! This water-washable, hydrophilic anti-fog lens coating is permanently bonded to the lens to absorb moisture and then spread it consistently, providing clear, fog-free vision
- Sport-inspired design for a fashionable look
- Dual-injected TPR ends for slip-free experience
- Optional foam gasket for protection from particles (BH14G)

### TECHNOLOGY

All Bullhead Safety® Eyewear is made from 100% virgin materials. This style features lenses and frames constructed with the highest quality polycarbonate.



\*Optional

- Meets ANSI/ISEA Z87.1-2020 standards
- Meets ANSI/ISEA Z87.1-2020 anti-fog properties standard

### SPECIFICATIONS

LENS	LIGHT TRANSMITTANCE	FRAME TYPE	FRAME COLOR	WEIGHT	BASE CURVE	FRAME WIDTH	TEMPLE LENGTH	END OF TIPS WIDTH
Clear PFT	89%	Full Frame	Crystal Black	31 Grams	8	130 mm	120 mm	105 mm

### PACKAGING

	EACH	INNER PACK	CASE
QUANTITY	1	12/box	12 boxes/case
UPC/GTIN	816368026244	10816368026241	20816368026248

13915 Radium St NW  
Ramsey, MN 55303

763-450-0110  
Sales@BullheadSafety.com

BullheadSafety.com

