

**SPEARFISH®  
READERS****PFT**  
PERFORMANCE FOG TECHNOLOGY**BULLHEAD SAFETY® EYE PROTECTION****BH225315PFT**

Retainer cord included with each pair of Spearfish® glasses.

**LENS Smoke Performance Fog Technology 1.5 Diopter Bifocal Reader Style****FRAME Shiny Black**

## DESCRIPTION

The Spearfish® has a flexible frame with vented temples, a TPR nose piece, and TPR temple ends. Designed to contour with the natural curvature of the head, the Spearfish® maximizes all-day wearability and comfort. Bifocal reader style lenses feature a magnification diopter positioned at the bottom inside of the lens. This improves workplace safety by eliminating the need to switch between safety and reading glasses. The BH225315PFT also features a PFT lens. Thanks to its chemical and physical properties, Performance Fog Technology is a permanent coating that prevents the formation of condensation on the lenses by absorbing the humidity drops.

Each dozen is packaged in a retail-ready box.

## FEATURES

- PFT - Performance Fog Technology lens: Better than traditional anti-fog! This water-washable, hydrophilic anti-fog lens coating is permanently bonded to the lens to absorb moisture and then spread it consistently, providing clear, fog-free vision
- Dual 8 base curve lenses for full protection and visual correctness
- Each pair includes a retainer cord
- Flexible and lightweight half frame design

## TECHNOLOGY

All Bullhead Safety® Eyewear is made from 100% virgin materials. This style features lenses constructed with the highest quality polycarbonate and frames made with nylon.

MEETS ANSI/ISEA  
Z87.1-2020  
STANDARDSMEETS  
ANTI-FOG  
STANDARDARC FLASH  
TESTED TO  
35 CAL/CM²ERGONOMIC FIT  
RELIEVES  
PRESSUREANTI-SCRATCH  
HARD COAT  
TREATED LENSPERMANENT  
HYDROPHILIC  
COATINGINCLUDES  
MAGNIFICATION  
DIOPTERTAPERED LENS  
ELIMINATES  
DISTORTIONFILTERS 99.9%  
UVA/UVB/UVC  
LIGHT RAYS

- TPR nose piece and temple ends
- Vented temples increase airflow
- Meets ANSI/ISEA Z87.1-2020 standards
- Meets ANSI/ISEA Z87.1-2020 anti-fog properties standard

## SPECIFICATIONS

LENS	LIGHT TRANSMITTANCE	FRAME TYPE	FRAME COLOR	WEIGHT	BASE CURVE	FRAME WIDTH	END OF TIPS WIDTH	TEMPLE LENGTH
Smoke PFT	12%	Vented Half Frame	Shiny Black	24 Grams	8	143 mm	78 mm	102 mm

## PACKAGING

	EACH	INNER PACK	CASE
QUANTITY	1	12/box	12 boxes/case
UPC/GTIN	810033293092	10810033293099	20810033293096

13915 Radium St NW  
Ramsey, MN 55303763-450-0110  
Sales@BullheadSafety.com

BullheadSafety.com

**Bullhead Safety®**