

DORADO®

BULLHEAD SAFETY® EYE PROTECTION

BH943PFT

PFT

PERFORMANCE FOG TECHNOLOGY



BH9G

Optional removable flame-resistant foam gasket is available for all Dorado® safety glasses.

*Optional see below

LENS Dark Smoke Performance Fog Technology

FRAME Crystal Black

DESCRIPTION

The lightweight, contemporary full frame of the Dorado® features dual lenses for improved protection and 100% visual correctness. Comfort-fit rubber temples and nose pieces prevent eyewear from slipping while also providing maximum comfort. The BH943PFT also features a PFT lens. Thanks to its chemical and physical properties, Performance Fog Technology is a permanent coating that prevents the formation of condensation on the lenses by absorbing the humidity drops.

BH9G - optional removable flame-resistant foam gasket available for all Dorado® safety glasses.

FEATURES

- PFT - Performance Fog Technology lens: Better than traditional anti-fog! This water-washable, hydrophilic anti-fog lens coating is permanently bonded to the lens to absorb moisture and then spread it consistently, providing clear, fog-free vision
- Wide-fit frame to fit a variety of face sizes
- Comfort-fit temples prevents slipping
- Contemporary full frame for improved protection

TECHNOLOGY

All Bullhead Safety® Eyewear is made from 100% virgin materials. This style features lenses and frames constructed with the highest quality polycarbonate.



MEETS ANSI/ISEA
Z87.1-2020
STANDARDS



MEETS
ANTI-FOG
STANDARD



ARC FLASH
TESTED TO
35 CAL/CM²



MEETS MILITARY
SPECS FOR
BALLISTICS



ERGONOMIC FIT
RELIEVES
PRESSURE



ANTI-SCRATCH
HARD COAT
TREATED LENS



PERMANENT
HYDROPHILIC
COATING



TAPERED LENS
ELIMINATES
DISTORTION



FILTERS 99.9%
UVA/UVB/UVC
LIGHT RAYS



PROVIDES SEAL
AGAINST DEBRIS
AND IMPACT
*Optional

- Meets ANSI/ISEA Z87.1-2020 standards
- Meets ANSI/ISEA Z87.1-2020 anti-fog properties standard

SPECIFICATIONS

LENS	LIGHT TRANSMITTANCE	FRAME TYPE	FRAME COLOR	WEIGHT	BASE CURVE	FRAME WIDTH	TEMPLE LENGTH	END OF TIPS WIDTH
Dark Smoke PFT	16%	Full Frame	Crystal Black	29 Grams	8	140 mm	123 mm	94 mm

PACKAGING

	EACH	INNER PACK	CASE
QUANTITY	1	12/box	12 boxes/case
UPC/GTIN	816368026275	10816368026272	20816368026279

13915 Radium St NW
Ramsey, MN 55303

763-450-0110
Sales@BullheadSafety.com

BullheadSafety.com

