

Cut, Abrasion, Puncture, and Impact Resistant Rubber-Coated High-Visibility Gloves

DESCRIPTION

This high-visibility seamless glove is a high-performance cut-resistant option with a 10-gauge yellow Aralene® (enhanced aramid fiber) shell. The orange-and-black flexible TPU on the back of the hand and fingers adds impact protection. The shell has a high-visibility orange, etched natural rubber latex-coated palm with padding underneath. The knit wrist provides a comfortable, secure fit.

INDUSTRY

Glass Handling	Metal Fabrication
Bottle Handling	Metal Stamping
Automotive	Oil and Gas
Construction	Lumber



FEATURES

- Puncture-resistant, etched-rubber palm retains flexibility and grip in low temperatures
- 10-gauge Aralene® (enhanced aramid fiber) shell offers both heat and cut resistance
- Soft, flexible, TPU impact protection over the fingers and metacarpal bones provides tough protection
- Padded palm increases comfort and dampens vibration
- Overcast color on hem for easy size identification
- Knit wrist cuff offers users a secure, comfortable fit and prevents gloves from slipping off during use
- EN 388 Levels: 2X44F
- EN 407 Levels: X3XXXX

ITEM CIA600KV

SIZES 7(S)-10(XL)

Meets ANSI/ISEA 105-2016 standard

- Cut Level A6
- ASTM F2992-15 Results = 3,391 grams
- Abrasion Level 4
- Puncture Level 4
- Puncture Results: 144 Newtons

Meets ANSI/ISEA 138-2019 standard

- Impact Level (Overall): 1
- Impact Level (Knuckles): 1
- Impact Level (Fingers/Thumb): 1



SPECIFICATIONS

SHELL	SHELL COLOR	GAUGE	COATING	COATING COLOR	FINISH	CUFF	IMPACT PROTECTION
Aralene®	Yellow	10-Gauge	Rubber	Orange	Etched	Knit Wrist	TPU
CUT	ASTM F2992-15 RESULTS	ABRASION	PUNCTURE	PUNCTURE RESULTS	IMPACT	EN 407 LEVELS	EN 388 LEVELS
Level A6	3,391 Grams	Level 4	Level 4	144 Newtons	Level 1	X3XXXX	2X44F

PACKAGING

	QUANTITY	7(S)	8(M)	9(L)	10(XL)
PAIR UPC	1	N/A	N/A	N/A	N/A
INNER PACK UPC	12/PACK	816679019935	816679019942	816679019959	816679019966
CASE GTIN	6 PK/CASE	10816679019932	10816679019949	10816679019956	10816679019963
CASE WEIGHT (IN POUNDS)		33	34.4	37.6	37.6
OVERCAST COLOR		Red	Green	Brown	Black