



HAND PROTECTION

High-Visibility Cut Resistant Gloves Made with Tuffalene® Platinum

DESCRIPTION

This lightweight seamless glove is an outstanding cut-resistant option that features a high-visibility yellow/green 15-gauge Tuffalene® Platinum shell. Our innovative Tuffalene® Platinum offers extra comfort, protection, and durability. Free from glass fiber or steel enhancements to achieve this level of cut protection. The shell is enhanced by a black Mach Finish nitrile dipped palm. Tuffalene® Platinum gloves offer a cooler, more comfortable user experience and feature cut and puncture resistance comparable to enhanced fibers. Gloves made with Tuffalene® Platinum last longer than enhanced gloves due to the inherent abrasion resistance of the fiber construction. Because Tuffalene® Platinum gloves are constructed without steel or glass fiber, particles of these fibers do not contaminate other materials during handling.



INDUSTRY	
Glass Handling	Construction
Bottle Handling	Metal Fabrication
Automotive Industry	Metal Stamping
Aerospace Industry	Steel Handling

ITEM **CR915MF**

SIZES **6(XS)-10(XL)**

FEATURES

- 15-gauge Tuffalene® Platinum UHMWPE shell offers bare hand sensitivity and cut resistance, free from glass fiber or steel enhancements
- Abrasion-resistant Mach Finish nitrile offers excellent grip in wet and oily conditions
- Overcast color on hem for easy size identification
- Knit wrist cuff offers users a secure, comfortable fit and prevents gloves from slipping off during use
- ANSI Cut Level A3
- ASTM F2992-15 Results = 1,093 grams
- EN 388 Levels: 4X43C



SPECIFICATIONS

SHELL	SHELL COLOR	GAUGE	COATING	COATING COLOR	COATING TYPE	FINISH	CUFF
Tuffalene® Platinum UHMWPE	High-Visibility Yellow/Green	15-Gauge	Nitrile	Black	Palm	Mach Finish	Knit Wrist

ANSI CUT	ASTM F2992-15 RESULTS	EN 388 LEVELS
Level A3	1,093 Grams	4X43C

PACKAGING

	QUANTITY	6(XS)	7(S)	8(M)	9(L)	10(XL)
PAIR UPC	1	NA	NA	NA	NA	NA
INNER PACK UPC	12/PACK	816679013889	816679013896	816679013902	816679013919	816679013926
CASE GTIN	6 PK/CASE	10816679013886	10816679013893	10816679013909	10816679013916	10816679013923
CASE WEIGHT (IN POUNDS)		9.8	10.4	11.3	12.6	14.4
OVERCAST COLOR		PURPLE	RED	GREEN	BROWN	BLACK

13915 Radium St NW
Ramsey, MN 55303

763-450-0110
Sales@GlobalGlove.com

GlobalGlove.com

