

Clear Aluminized Polycarbonate Face Shield

**ITEM HH-V2**

*Hard hat not included.
Shown attached to cap style aluminum bracket - HH-AB1 (sold separately).

FEATURES

- 8" X 15.5" aluminized polycarbonate face shield
- 1 mm thick
- Universal slots will accommodate a wide variety of headgear
- Provides 99.9% UVA/B/C protection
- Meets ANSI/ISEA Z87.1-2020 high impact standards
- Bulk packed with UPC on each shield, 140 PCS/CS

Face Shield Attachment Instructions:

- Beginning at one end, place the oval holes that are along the top of the face shield over the corresponding latching mechanisms on the visor
- Once the holes are over the latching mechanisms, twist them 90 degrees down until the face shield is secure

DESCRIPTION

This aluminized polycarbonate face shield has universal slots that accommodate a wide variety of headgear. The shield is 1 mm thick and eight inches wide by 15.5 inches tall, giving full protection for the face. Features 99.9% UVA/B/C protection from harmful rays.

PACKAGING

	QUANTITY	HH-V2
EACH UPC	1	816368029733
INNER PACK GTIN	35 EA/CASE	10816368029730
CASE GTIN	20 PKS/CASE	20816368029737
CASE WEIGHT (IN POUNDS)		41.3

SPECIFICATIONS

MATERIAL	SIZE	THICKNESS	PACKAGING	MEETS ANSI/ISEA Z87.1-2020 STANDARDS
Clear Aluminized Polycarbonate	8 in. x 15.5 in.	1 mm	Bulk Packed with each UPC's 140 pcs/cs	Yes