

# BULLHEAD SAFETY™ HEAD PROTECTION

## Clear Toric Polycarbonate Face Shield



ITEM **HH-V5**

\*Hard hat not included.  
Shown attached to cap style plastic bracket - HH-PB1 (sold separately)

### FEATURES

- 8" X 15" toric polycarbonate face shield
- 2 mm thick
- Universal slots will accommodate a wide variety of headgear
- Provides 99.9% UVA/B/C protection
- Meets ANSI/ISEA Z87.1-2020 high impact standards
- Individually packaged, 40 PCS/CS

#### Face Shield Attachment Instructions:

- Beginning at one end, place the oval holes that are along the top of the face shield over the corresponding latching mechanisms on the visor
- Once the holes are over the latching mechanisms, twist them 90 degrees down until the face shield is secure

### PACKAGING

|                         | QUANTITY   | HH-V5          |
|-------------------------|------------|----------------|
| EACH UPC                | 1          | 816368029795   |
| CASE GTIN               | 40 EA/CASE | 10816368029792 |
| CASE WEIGHT (IN POUNDS) |            | 15.3           |

### SPECIFICATIONS

| MATERIAL            | SIZE             | THICKNESS | PACKAGING                         | MEETS ANSI/ISEA Z87.1-2020 STANDARDS |
|---------------------|------------------|-----------|-----------------------------------|--------------------------------------|
| Toric Polycarbonate | 8 in. x 15.5 in. | 2 mm      | Individually Packaged - 40 pcs/cs | Yes                                  |

13915 Radium St NW  
Ramsey, MN 55303

763-450-0110  
Sales@BullheadSafety.com

BullheadSafety.com

