

## High-Visibility Cut and Impact Resistant Buffalo Leather Drivers Gloves

### DESCRIPTION

These cut and impact-resistant leather drivers gloves are premium-grade white grain buffalo leather. They have a gunn cut pattern, a thin woven Tuffalene® UHMWPE inner liner, and high-visibility orange TPR impact protection over the fingers and metacarpal bones. The keystone thumb provides good durability and comfort, while the open cuff with a hook-and-loop closure gives a secure fit. The buffalo leather is sewn with aramid fiber for added cut protection.

Each pair is individually packaged in a polybag.



### INDUSTRY

Agriculture	Fabrication	Machine Operation
Carpentry	Infrastructure Maintenance	Maintenance
Construction	Lumber Industry	Manufacturing
Demolition		

### FEATURES

- Premium-grade grain buffalo leather provides excellent wear resistance, durability, breathability, and flexibility
- Thin Tuffalene® UHMWPE liner is sewn into the glove and offers great dexterity and cut resistance
- High-visibility orange TPR impact protection
- Soft, flexible, TPR impact protection over the fingers and metacarpal bones provides tough protection
- Sewn with aramid fiber for added durability and cut resistance
- Gunn cut pattern
- Ergonomic keystone thumb improves durability, comfort, and dexterity while reducing hand fatigue
- Open cuff with a unique hook-and-loop closure secures gloves to wrist to prevent loss or slipping while also allowing for easy donning and removal
- EN 388 Levels: 3X43FP

ITEM **CIA7700**

SIZES **7(S)-11(2XL)**

**Meets ANSI/ISEA 105-2016 standard**

- Cut Level A7
- ASTM F2992-15 Results = 4,526 grams
- Abrasion Level 5
- Puncture Level 5
- Puncture Results: 156 Newtons
- Conductive Heat Level 3



**Meets ANSI/ISEA 138-2019 standard**

- Impact Level (Overall): 2
- Impact Level (Knuckles): 3
- Impact Level (Fingers/Thumb): 2

### SPECIFICATIONS

SHELL	SHELL COLOR	LINER	COLOR		PATTERN	STITCHING	THUMB	CUFF
Grain Buffalo	White	Tuffalene® UHMWPE	White with High-Visibility Orange		Gunn Cut	Aramid	Keystone	Open Plus Hook-and-Loop
IMPACT PROTECTION	CUT	ASTM F2992-15 RESULTS	ABRASION	PUNCTURE	PUNCTURE RESULTS	IMPACT	CONDUCTIVE HEAT	EN 388 LEVELS
TPR	Level A7	4,526 Grams	Level 5	Level 5	156 Newtons	Level 2	Level 3	3X43FP

### PACKAGING

	QUANTITY	7(S)	8(M)	9(L)	10(XL)	11(2XL)
PAIR UPC	1	NA	NA	NA	NA	NA
INNER PACK UPC	12/PACK	810033295799	810033295805	810033295812	810033295829	810033295836
CASE GTIN	3 PK/CASE	10810033295796	10810033295802	10810033295819	10810033295826	10810033295833
CASE WEIGHT (IN POUNDS)		19.6	20	23.95	24.6	25.6
OVERCAST COLOR		Red	Green	Brown	Blue	Yellow