

High-Visibility Cut, Impact, Oil, and Water-Resistant Premium Leather Drivers Gloves

DESCRIPTION

These leather drivers gloves are cut, impact, oil, and water-resistant. Made with premium-grade white grain goatskin leather, these oil and water-resistant gloves have a gunn cut pattern and a thin woven Aralene® (enhanced aramid fiber) inner liner. The high-visibility orange TPR impact on the back of the hand and fingers provides extra protection. These leather gloves also have an elastic loop at the cuff for easier donning. Features a keystone thumb and open cuff plus hook-and-loop closure. Sewn with aramid fiber for added durability. Each pair is individually packaged in a polybag.



INDUSTRY

Agriculture	Demolition	Manufacturing
Carpentry	Fabrication	Masonry
Construction	Maintenance	Oil and Gas



FEATURES

- Premium-grade grain goatskin leather offers ultimate dexterity
- Proprietary oil/water resistant manufacturing process to ensure longer lasting benefits over a spray-on treatment
- Thin woven Aralene® inner liner offers great dexterity, cut resistance, and heat resistance
- Sewn with aramid fiber for added durability and cut and heat resistance
- Soft, flexible, TPR impact protection over the fingers and metacarpal bones provides tough protection

- Ergonomic keystone thumb improves durability, comfort, and dexterity while reducing hand fatigue
- Overcast color on hem for easy size identification
- Elastic loop sewn inside of the cuff
- EN 388 Levels: 3X43FP

Meets ANSI/ISEA 138-2019 standard

- Impact Level (Overall): 2
- Impact Level (Fingers/Thumb): 2
- Impact Level (Knuckles): 3

ITEM CIA7900 SIZES 7(S)-11(2XL)

Meets ANSI/ISEA 105-2016 standard

- Cut Level A9
- ASTM F2992-15 Results = 6,577 grams
- Abrasion Level 4
- Puncture Level 4
- Puncture Results: 106 Newtons
- Conductive Heat Level 2

SPECIFICATIONS

SHELL	SHELL COLOR	LINER	LINER COLOR	THUMB	CUFF	IMPACT PROTECTION	CUT	ASTM F2992-15 RESULTS
Grain Goatskin	White	Aralene®	Yellow	Keystone	Open with Hook-and-Loop	TPR	Level A9	6,577 grams
ABRASION	PUNCTURE	PUNCTURE RESULTS		IMPACT		CONDUCTIVE HEAT	EN 388 LEVELS	
Level 4	Level 4	106 Newtons		Level 2		Level 2	3X43FP	

PACKAGING

	QUANTITY	7(S)	8(M)	9(L)	10(XL)	11(2XL)
PAIR UPC	1	NA	NA	NA	NA	NA
INNER PACK UPC	12/PACK	810033296581	810033296598	810033296604	810033296611	810033296628
CASE GTIN	3 PK/CASE	10810033296588	10810033296595	10810033296601	10810033296618	10810033296625
CASE WEIGHT (IN POUNDS)		19.4	20.7	22.3	23.05	25.9
OVERCAST COLOR		Red	Green	Brown	Blue	Yellow

13915 Radium St NW
Ramsey, MN 55303

763-450-0110
Sales@GlobalGlove.com

GlobalGlove.com


Global Glove
& Safety Manufacturing, Inc.